

REMOTE RACKING SYSTEM

SPECIFICALLY DESIGNED FOR:

STR SAFE-T-RACK®

by Remote Solutions LLC

Because Distance is the Best Arc Flash Protection

BREAKER: FB/FC

MANUFACTURER: Allis-Chalmers, Siemens


VOLTAGE: 15kV

CURRENT: 1200A, 2000A

CROCODILE

171

CROCODILE
STR
TOOL CODE®



- **LIGHTWEIGHT AND PORTABLE**
- **EASY-TO-USE HANDHELD CONTROLLER**
- **STANDARD 50' CABLE (WITH OPTIONAL EXTENSIONS) ASSURES SAFE DISTANCE FROM BREAKER DURING RACKING SEQUENCE**
- **ERROR RECOVERY & EMERGENCY STOP CAPABILITY**
- **NO-MOD DESIGN - NO PERMANENT CHANGES TO CUBICLE OR EQUIPMENT REQUIRED**

PARTS & ACCESSORIES

Smart Drive Bracket,
Tool Adapter Assembly, Motor Drive Unit,
Handheld Controller,
and 50' Communications Cable

All of our products are designed, built to spec, and shipped from our state-of-the-art facility in Tucson, Arizona. Each product is created and tested by our knowledgeable team of designers and engineers to fit each individual breaker, cubicle door, switchgear, or variant. When you choose Safe-T-Rack, you're getting the safest, most reliable product on the market.

**OUR TEAM GOES TO WORK EVERY DAY
TO MAKE SURE YOUR TEAM
COMES HOME SAFE.**



REMOTE SOLUTIONS, LLC

2475 N. Jackrabbit Avenue · Tucson, AZ 85745 · (520) 628-4378 ·
FAX (520) 628-4568 · www.Safe-T-Rack.com

**MADE IN THE
USA**

BREAKER: FB/FC

MANUFACTURER: Allis-Chalmers, Siemens

VOLTAGE: 15kV

CURRENT: 1200A, 2000A

SAFETY FIRST


Always observe safety precautions and use personal protective equipment (PPE) as required by local site procedures. This equipment is designed to further minimize exposure risk to the operator.

PARTS LIST

1. Spanner Bar
2. Smart Drive Bracket (SDB) - Thrust Assembly
3. Interlock Manipulator
4. Motor Drive Unit (MDU)
5. Two (2) batteries with charger
6. One (1) SR-U Handheld Controller (HHC)
7. 50' Communication Cable*
8. Polymer Storage Case



4



Magnet Clamps

XLR Cables

3

Locking Pin

Drive Rings

1

2



Navigation & Selection Buttons

Power/E-Stop Button

6

7



8



5

WARNING

This product can expose you to chemicals including Di(2-ethylhexyl), phthalate (DEHP), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.p65warnings.ca.gov.

SETUP SEQUENCE

SPANNER BAR, SMART DRIVE BRACKET (SDB) THRUST ASSEMBLY AND INTERLOCK MANIPULATOR

1. Assure that cubicle, spanner bar, and Smart Drive Bracket (SDB) are all labeled with CROCODILE color code.
2. Place Spanner Bar across opening of cubicle so that it fits snugly against cubicle walls. Once Spanner bar is placed correctly, secure Spanner Bar in place using locking clamps.
3. Place SDB Thrust Assembly by hooking mounting pin on SDB beneath foot pedal of breaker and resting the body of thrust assembly on spanner bar. Spring loaded latch near mounting pin will lock thrust assembly in place.
4. Mount Interlock Manipulator by fitting mounting clip onto cubicle above and to the right of the foot pedal. Once flush against the breaker, secure Interlock Manipulator in place using magnet clamps.
5. Connect XLR cable on SDB Thrust Assembly with Interlock Manipulator XLR cable, ensuring cord will not be pinched or pulled during racking process.

MOTOR DRIVE UNIT (MDU)

1. Attach fully charged battery to MDU.
2. Set the locking pin on SDB to an open position and insert MDU into the drive rings on SDB.
3. Align and engage the MDU with drive rings. Once aligned, release locking pin to hold MDU in place. Confirm that MDU is secured before proceeding.
4. Connect SDB communication cable to port in MDU. Note: *Red line on communication cables indicates correct alignment with port.*

HANDHELD CONTROLLER (HHC)


1. Connect 50' Communication Cable to second port in MDU.
2. Connect other end of 50' Communication Cable to Handheld Controller (HHC)*.
3. Move a safe distance away from the breaker.




SPANNER BAR PLACED ACROSS CUBICLE - TOGGLE CLAMPS LOCKED



SDB TRUCK ASSEMBLY PLACED ON SPANNER BAR WITH MOUNTING PIN ENGAGED



INTERLOCK MANIPULATOR CORRECTLY MOUNTED, LOCKED IN PLACE WITH MAGNET CLIPS



MDU ENGAGED WITH DRIVE RINGS AND LOCKING PIN, READY FOR SDB AND HHC COMMUNICATION CORDS

*Note: Multiple cables can be used to increase safe distance from breaker. Additional cables sold separately. Contact Remote Solutions LLC for more information.

POWER ON

1. Twist the E-Stop switch on HHC to activate the system.
2. Several screens will flash as unit powers up. Once HHC has powered up, **verify correct application screen is displayed.**

SYSTEM OPERATION

1. Follow the on-screen prompts to complete racking procedure. Navigate selections using perimeter buttons on HHC (backlit in green). “Right” and “Left” will advance through menu screens. “Up” and “Down” will toggle selections on screen.
2. Navigating HHC in this manner, select current location and desired destination of breaker. When selection is highlighted, click center button (backlit in red) to confirm selection. **This will initiate the racking process.**
3. System will perform action as selected, displaying progress on screen.
4. Upon successful operation, HHC will display a completed racking screen.

POWER DOWN & STORAGE

1. Power down the unit by pressing the E-Stop button. Remove battery from MDU.
2. Unplug power cord and HHC communication cord from SDB. Unplug XLR cable between Interlock Manipulator and SDB Truck Assembly.
3. Stow 50’ Communication Cable, HHC, MDU, and batteries in storage case.
4. Release magnet clamps and remove Interlock Manipulator and SDB Truck Assembly. Release toggle clamps and remove Spanner Bar from cubicle. Store each piece in provided polymer case.

BATTERY REQUIREMENT

Note: System will ask to verify battery level. Check battery level is at 4 bars before attempting to rack. If racking multiple breakers, please verify battery level between each racking attempt.



CARE & MAINTENANCE

To ensure longevity of the Portable Kit and SDB, store the tools in the provided polymer case in a dry, temperate environment. The tools are weather resistant but should be used with care in rain and snow.

Remote Solutions reserves the right to change or update product or documentation without prior notice.

ERROR RECOVERY

If a problem occurs, programmed recoveries will happen automatically and the system will attempt to recover the breaker to a known position.

When racking in/out, if an obstruction or mechanism failure occurs, the system will attempt to recover the breaker to a safe position. Actions will be displayed on HHC with an asterisk (*) in front of them. When the system has completed recovery operations, HHC will display current expected location of the breaker. Note the expected location and approach the breaker with caution. Determine cause of the failure and remedy the situation prior to attempting additional remote racking.

NOTE: Attempting to stop or shutting down the system mid-process once it has started is not recommended, as this will leave the breaker in an unknown position. The Remote Racking System will only operate from known positions.



EMERGENCY STOP

The red E-Stop button on the HHC serves as both the power and Emergency Stop button. If an E-stop is initiated, the system will shut down. Operator must then manually recover the breaker to a known position. Follow all safety procedures and wear appropriate PPE when recovering a breaker manually.

For any questions, concerns, information, or missing/replacement parts, contact Remote Solutions below or follow the QR link to our website.



SR **SAFE-T-RACK**
by Remote Solutions LLC

2475 N. Jackrabbit Avenue · Tucson, AZ 85745 · (520) 628-4378

FAX (520) 628-4568 · sales@Safe-T-Rack.com · www.Safe-T-Rack.com