

SRN Remote Motor to Local Motor Adapter

Safe-T-Rack® SRN Remote Racking Bypass Device

Application Summary

Functions/Features

- Install round 14 pin plug in door mounted receptacle
- Mount "local" motor on platform
- Apply cable harness by installing the 8 pin plug into the J-Box receptacle and mate the 4 pole receptacle with the 4 pin plug on the local motor
- Select direction of breaker travel by using the motor mounted toggle switch "raise" or "lower"
- Pull slide clutch handle forward to engage the slide clutch with motor coupling simultaneously starting the motor
- Motor will function as per original switchgear racking design





Because Distance is the Best Arc Flash Protection

