




SAFE-T-RACK
by remote solutions, llc

**Operation
Manual**



SR-U

SDB-60A8-3040




General Electric

AKR-75/-100

480-600V

3000-4000A



Our products are built to spec in our 23,000 sq ft., state-of-the-art facility by our team of designers and engineers in Tucson, Arizona. Each product is custom designed to individually fit each breaker, cubical door, switch gear, or variant so you know you're getting the safest, most reliable product on the market. We built the best so your team stays safe.

Because Distance is the Best Arc Flash Protection



REMOTE SOLUTIONS, LLC

2475 N. Jackrabbit Avenue ■ Tucson, AZ 85745 ■ (520) 628-4378 ■ FAX (520) 628-4568 ■ Safe-T-Rack.com

Safety First

Always observe all safety precautions and use all personal protective equipment (PPE) as required by Local Site Procedures. This equipment is designed to minimize exposure risk to the operator. Please use the cables, explained below, to attain a safe distance from the breakers during racking. Always use appropriate PPE. Above all, adhere to site specific regulations and requirements.

Before beginning the racking process, be sure that the breaker is open, verify that a lockout/tag out is in place (LOTO) and allows racking of the breaker.

Parts List

Part/Image	Quantity	Description
	1 each	The Smart Drive Bracket (SDB) uses the Tool Adapter Assembly (TAA) to engage with the breaker and perform the racking in/out functions.
	1 each	Portable Kit includes: One Motor Drive Unit (MDU), one 50' comm. cable, two 28V batteries, and one SR-U Handheld Controller (HHC)

Operation Manual

Overview

Depicted in fig. 1.1, the Smart Drive Bracket (SDB) includes a Custom Tool Adapter (CTA), not depicted here. The CTA couples with a Motor Drive Unit (MDU). Once coupled with the CTA, the MDU fits through the red mounting rings, seen in both figs. 1.1 and 1.2. These rings are spring loaded to maintain a secure connection between the CTA and the racking shaft.

The CTA is designed to be disassembled and cut to length, if necessary. Depending on the distance from the mounting rings to the racking shaft, the CTA may be trimmed down for the best possible fit. Once the CTA is cut and MDU is mounted, the racking function may be performed.




Fig. 1.1




Fig. 1.2

Tool Adapter Mount

As noted in the Overview, the SDB is equipped with a Custom Tool Adapter (CTA). The Motor Drive Unit (MDU) is equipped with a quick-connect tool coupling, which uses a collar that slides back and the CTA inserts in to the coupling. When the coupling is released, the CTA is secured in place.

Sequence Process

1. Pull back the collar on the MDU.
2. Insert the CTA in to the quick-connect tool coupling.
3. Release the collar and shake and twist the CTA to ensure its locked in place.




Fig. 1.3

Smart Drive Bracket Mount

On the face of the breaker door, there are four Shoulder Nuts (indicated below). The SDB will eventually hang from these four nuts. The SDB is equipped with four keyhole slots that align with the Shoulder Nuts. This is where the SDB will connect.

Sequence Process

1. Identify Shoulder Nuts and racking port.
2. Align the keyhole slots and the mounting ring on the SDB over the Shoulder Nuts and racking port, respectively, and hang the SDB




Fig. 1.4

Motor Drive Unit Mount

The Portable Kit includes two 28V batteries. Before connecting the battery to the system, make sure the battery is fully charged and is attached to the MDU. If preferred, an AC Power Supply is available, negating the need of a battery.

The MDU intuitively fits into the SDB mounting rings (depicted in red), on top of which is a locking pin (depicted in green, fig. 1.5). Set the locking pin to the open position. Insert the MDU and align the CTA with the racking shaft, then lock the MDU into place by releasing the locking pin. When the pin fully engages, the MDU is secure.

Once the MDU is secured to the SDB and fully connected to the Tool Adapter, connect the 50 foot SDB Automation Cable to the Motor Drive Unit.

Sequence Process

1. Attach a fully charged battery to the MDU.
2. Set the locking pin to the open position.
3. Insert the MDU equipped with the CTA through the mounting rings.
4. Align and engage the CTA with the racking shaft.
5. Release the locking pin, securing the MDU in place.
6. Connect the SDB Automation Cable to the MDU.




Fig. 1.5



Handheld Controller

The Handheld Controller connects to the MDU via a 50' Automation Cable. If necessary three cables may be tethered to achieve a safe distance of 150'. Once plugged in and turned on, the Handheld Controller guides the user through the racking in/out procedure.

Sequence Process

1. Connect the Handheld Controller with the 50' Comm. Cable.
2. Move a safe distance from the breaker.
3. Twist the E-Stop switch, depicted here, to activate the HCC.
4. Turn on the Handheld Controller and follow the on-screen prompts.

Error Recovery

When racking in/out, if an obstruction or mechanism failure occurs, the system will attempt to recover the breaker to a safe position. Actions will be displayed with an asterisk (*) in front of them. When done, the position of the breaker will be displayed as determined by the recovery. Note the location and approach with caution. Determine the cause of the failure and remedy the situation prior to attempting additional remote racking.

NOTE: Attempting to stop or shutting down the system mid-process once it has started is not recommended, as this will leave the breaker in an unknown position. The Remote Racking System will only operate from "known" positions: connect or disconnect. The Remote Racking System will not engage when the breaker is at a mid-point.



Care/Maintenance

To ensure longevity from the Portable Kit and the Smart Drive Bracket, store the tools in the provided polymer case in a dry, temperate environment. The tools are weather resistant but should be used with care in rain and snow.

WARNING

This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

For any questions, concerns, information, or missing/replacement parts, contact Remote Solutions below or follow the QR link to our website.



Because Distance is the Best Arc Flash Protection

Remote Solutions, LLC

2475 N. Jackrabbit Avenue
Tucson, AZ 85745
(520) 628-4378
sales@safe-t-rack.com
www.safe-t-rack.com